

Checklist for Installation and Troubleshooting:

1. Power Connection Required:

- The **red wire must be connected to +12V ignition power (ACC)**.
Without power, the amplifier will not function at all.

2. Ground Connection:

- The **black or green wire** must be properly grounded to the car chassis (metal surface) or a reliable GND point.

3. Radio Settings:

- Some car radios require **activating "antenna power" (ANT PWR)** in the system settings.
Without this, the amplifier won't receive voltage.

4. DAB Antenna Plug (SMB f):

- Ensure the **SMB connector is fully inserted** into the DAB antenna port. A loose or missing connection will result in no DAB signal.

5. Physical Damage or Improper Installation:

- Avoid sharp bends or pulling the wires.
Also, ensure polarity is correct when connecting to 12V.