

### **Mounting Kit**

Ver. 4/05

1. Open drink holder half way and remove the (2) Phillips screws from this location.

Open the glove box and depress both sides to lower the glove box out of the way.

Gently pull outward on the dash trim bezel starting at the bottom and work your way to the top.

Disconnect the (2) heater, A/C control cables from below the steering wheel. (You will see a yellow gear with

a cable and a white gear with a cable attached towards the right side.) Detach the cables from the gears and

Disconnect the (1) heater control cable from the heater box, and unfasten the clip from the cable

2002-05 Hyundai Accent

DASH DISASSEMBLY INSTRUCTIONS

# **NOTE:** The yellow gear connects to the cable with the yellow foam covering.

unfasten the mounting clips from the cables.

- Disconnect the Clock, Hazard, and Rear Defogger harnesses and lean the dash Gently pull dash trim bezel forward. trim bezel out of the way.
- Remove the (4) Phillips screws securing the radio to the sub-dash.
- Pull radio forward, disconnect the wire harness and antenna lead and remove the radio.

KIT ASSEMBLY INSTRUCTIONS

- Attach the left & right ISO mounting brackets to the left & right sides of the face of kit.
- Remove the trim ring from the after market radio.
- Insert the aftermarket radio into the kit from the rear and attach to the kit using the screws supplied with the aftermarket radio.

## non flip-face style radios

the side mounting screws. Adjust the radio forward or backwards until you have the desired look, and tighten

## FLIP-FACE style radios

Hyundai 2002-05 ACCENT

VEHICLE APPLICATIONS (Single ISO Application)

of the radio does not clear the lower lip of the kit, adjust the radio backwards until the face of the radio Adjust the radio forward and tighten the side mounting screws and open the face of the radio. If the face opens unobstructed and tighten the side mounting screws.

- Wire the radio and install into dash using the (4) screws supplied with the kit.
- Reassemble dash in reverse order of dash disassembly from steps 1 thru 8.